

let's feel the sound



let's feel the sound



www.lasmex.com

Anholtseweg 38
7091 HB Dinxperlo

User guide

- * Please insure at least 8 hours' battery fully charging for the first time;
- * Connect the line out cable with the 3.5 jack of the Bluetooth Box;
- * Step 1: Press and hold the power button (about 10s) until the LED indicator flashing red and blue in turn;
- * In the state of searching, your player can search the device named as Lasmex LBT10, then click the confirmation key to connect;
- * The effective transmission range is 100cm (about 1m) for the first time;
- * If the connection between the device and player could not be made within 2 minutes, then the device will be close to search;
- * If connection with the new device need to be made, you need to turn off the device and then follow step 1;
- * If you want to connect different bluetooth device, what you need to do is turn off the device and follow step 1;

01

- * The bluetooth system can connect with one device each time and connecting with many devices at the same time could not be supported; If player device need to be changed, you need to stop the working player and then follow step 1;
- * If the device has record on player, then you can choose the device "Lasmex LBT10" and connect directly and the searching is not needed;
- * The effective transmission range is about 10m in places without interference and obstacles;

02

Lasmex LBT10 functional keys' instruction

- ▶ Play/Pause, play music and Pause to play music;
- ◀ Volume (-) decrease volume
- ▶ Volume (+) increase volume
- ◀◀ backforward: back to previous song
- ▶▶ forward: forward to next song
- ⏻ Power: Turn on/Turn off

03

Benutzerhandbuch

- Bitte Achten Sie darauf, dass der Akku mindestens acht Stunden, beim ersten Anschließen an eine Stromquelle, geladen wird.
- Verbinden Sie das Line-Out Kabel mit der 3,5mm Steckbuchse der Bluetooth-Box.
- Schritt 1: Drücken und Halten Sie den Power Knopf (für 10s) bis die LED-Leuchte in Rot/Blau abwechselnd aufleuchtet.
- Während des Suchvorganges kann der Player das Gerät, mit der Bezeichnung LBT10, finden, danach klicken Sie zum Verbinden auf die Bestätigungstaste.
- Die Effektive Übertragungsbereich beträgt erstmalig 100cm (ca. 1m).
- Falls die Verbindung, zwischen dem Gerät und dem Player, nicht innerhalb von Zwei Minuten hergestellt ist, wird die Suche abgebrochen.

04

- Falls die Verbindung in jedem Fall hergestellt werden soll schalten Sie das Gerät ab und folgen dann „Schritt 1“.
- Falls Sie andere Bluetooth-Geräte verbinden möchten, schalten Sie das Gerät ab und folgen „Schritt 1“
- Das Bluetooth-System kann jederzeit mit einem Gerät verbunden werden, Verbindungen mit mehreren Geräten zur selben Zeit werden nicht unterstützt. Falls das Wiedergabegerät geändert werden soll, müssen Sie das Gerät ausschalten und anschließend „Schritt 1“ folgen.
- Falls das Gerät bereits verbunden wurde und in Ihrem Mobiltelefon bereits ein entsprechender Eintrag vorliegt, so können Sie direkt verbinden, ohne, dass eine erneute Suche notwendig wäre.
- Die effektive Übertragungsbereich, in Umgebungen ohne Beeinträchtigungen und Hindernissen, beträgt bis zu 10m.

05

Lasmex LBT10 Funktionstasten – Leitfaden

- ▶ Play/Pause, Musik abspielen und pausieren
- ◀ Volume (-), Lautstärke mindern
- ▶ Volume (+), Lautstärke erhöhen
- ◀◀ Zurück zum letzten Lied
- ▶▶ Weiter zum nächsten Lied
- ⏻ Power: Einschalten/Ausschalten

06